

## HyperTerminal Configurations

These are preconfigured HyperTerminal setups(.ht files) for:

[WinNT](#) [WinXP](#)

For other communications programs the parameters should be set as follows:

Baud	1200
Data	7 bits
Parity	Odd
Handshaking	xon/xoff
Local Echo	On
Outgoing lf	Off
Incoming lf	On